

Thank you for choosing Rosetta hardscape products. The following are some helpful tips to make your first installation go smoothly. For more in-depth technical information, see our Rosetta Technical Guide (available at [rosettahardscapes.com](http://rosettahardscapes.com)) or contact Rosetta Tech Support.

*Your safety is important to us. Please follow OSHA guidelines, and utilize safety-toe boots, hardhats, gloves and eye, ear & respiratory protection whenever appropriate.*

## BLEND MULTIPLE PALLETS

- In order to achieve the best possible color blend, utilize material from multiple pallets simultaneously (when applicable).

## PROPER SETBACK

- To achieve proper setback in a retaining wall (4°), place each row of block ¼" back from the previous row. (see graphic on reverse side of this sheet)

## AVOID VERTICAL SEAMS

- Lay blocks in a random order to avoid the appearance of vertical seams.

## CONVEX RADIUS WALLS

- Convex curved walls can be made with a minimum radius of 14 ft.

## GLUE FOR STRENGTH

- For additional wall stability, adhere rows of block together with landscape adhesive.

## REQUIRED TOOLS

- PLATE COMPACTOR
- SHOVEL
- RAKE
- LEVEL
- DEAD BLOW HAMMER

### OPTIONAL TOOLS:

- TRANSIT LEVEL
- STRING LINE
- CUT OFF SAW
- LANDSCAPE ADHESIVE


### OTHER:

- NON-WOVEN GEOTEXTILE FABRIC
- 4" PERFORATED DRAIN PIPE
- GEOGRID


# CLAREMONT QUICK INSTALL TIPS

## TYPICAL RETAINING WALL SECTIONS


### GRAVITY, NON-REINFORCED (0-1 1/4 FT TALL [EXPOSED] WITH NO SURCHARGE)



### REINFORCED (GENERALLY 1 1/2 FT TALL AND ABOVE, AS REQUIRED IN THE ROSETTA TECHNICAL GUIDE)



## TYPICAL FREESTANDING WALL SECTION



## COLUMN INSTALLATION

\*Requires Corner Blocks

