

- *Toe slope bench width and bury depth as shown are intended to provide general guidance for embedment.
- Block sizes and placement shown are for reference only. Individual Outcropping blocks will vary with installation pattern.
- Retaining wall toe slopes tend to reduce bearing capacity and global stability.
- Final wall design must address these items, and shall be evaluated by the Professional Engineer who is responsible for the wall design.

This drawing is for reference only. Determination of the suitability and/or manner of use of any details contained in this document is the sole responsibility of the design engineer of record. Final project designs, including all construction details, shall be prepared by a licensed professional engineer using the actual conditions of the proposed site.

DRAWN BY: DLH/MRV	TITLE:	$\bigcirc \bigcirc $
APPROVED BY: NWL	TYPICAL TOE SLOPE DETAIL	O S E I I A
date: 15-JUL-2025		HARDS CAPES, LLC
SHEET NO.:	Typical Toe Slope Detail.dwg	8212 M-119 HARBOR SPRINGS, MI 49740 877-777-6558 • www.rosettahardscapes.com